

ASKER

Art.1516xx0011 G24q-2 TC-DEL 18W

Art.1517xx0011 G24q-2 TC-DEL 18W

(NOR) : For uplight snu kun frontdeksel, bakplate/veggfeste skal ikke vendes.














(SWE) : Vid upp-ljus vänd endast fronten, väggfästet skall inte vändas.

(ENG) : Important: do not turn the wallplate, only turn the front for uplight


(FR) : Important : ne pas tourner la plaque arrière pour un éclairage vers le haut! Pensez simplement à tourner la façade vers le haut.

(DE) : Wichtig: für Lichtauslass nach oben, bitte nicht die Wandplatte drehen! Nur das Gehäuse darf nach oben gedreht werden.


(PL) : Uwaga: Nie obracać tylnej płyty. Wybór kierunku świecenia poprzez obrót frontu.

**Important: Do not turn the wallplate.****Important: Do not turn the wallplate.**

$\leq 1,5^\circ$ x=10mm
 $1,5 \div 2,5^\circ$ x=12mm



3x max.2,5°



INSTR. N°1516xx0011

N°1517xx0011 VII/2016